


K46CM Repair Guide


BLOCK DIAGRAM

K46VM SCHEMATIC R1.0



www.bdbios.com


POWER FLOW



www.bdbios.com

POWER ON SEQUENCE

U53 Power On Sequence Diagram Rev.0.14




www.bdbios.com

Voltage& Signal Measure Point TOP



Voltage & Signal Measure Point Bottom



www.bdbios.com